


Manual tuning key. Press this key in order to manually tune a station. This key DOES NOT store a station, it simply allows you to tune. Use in conjunction with the tuning knob

Preset keys



Preset key tuning knob. Each key has its respective tuning knob located directly below it. Lift key to access round tuning knob. Rotate tuning knob to adjust. Press key to store or recall preset.

Tuning

On/off & volume control

**Band Selection
(Rotates drum)**

3 Level Tone Adjust

