

# Ferrari Cascade Radio Setup Language



- The operation can only be performed with the Flash Memory card in place
- The card will be in the leather pouch or accessory envelope delivered with the car


## Ferrari Cascade Radio Setup Language




1-Slide Emblem to Right



2-Remove Knob Plate



3- Locate Memory Card Slot



4-Insert Card in Slot

## Ferrari Cascade Radio Setup Language

- With the radio ON
- Push the “Info Button”




- The Main Info Screen will display



## Ferrari Cascade Radio Setup Language


- Scroll the tuner knob to the Voice Setting screen



- Push the knob "OK"



## Ferrari Cascade Radio Setup Language



Select "Set System Language"




Select "English US"

## Ferrari Cascade Radio Setup Language





Select Male or Female Voice



When prompted for the CD, push OK



## Ferrari Cascade Radio Setup Language



- Ignore the message click OK
- Restart radio (Off/On)
- A second error may appear
- Ignore the message click OK
- Restart radio (Off/On)